



Aquatic Consulting Services

356 Sumner Ave. • P.O. Box 1418 • Avalon • California • 90704
Santa Catalina Island • (619) 602-4435 • alison@alisonosinski.com

Boating Tip #26: Light List – San Diego Bay

Pt. Loma Lighthouse 32° 39.90' N 117° 14.57' W	Flashing WHITE (15 seconds) - 88' - 22 miles Horn: 1 blast every 30 seconds Pyramidal tower next to USCG white buildings
San Diego Approach 32° 37.3' N 117° 14.8' W	Morse code A – WHITE - 6 miles Racon M (-- --), Whistle “SD” red and white striped buoy
Buoy 3 32° 38.13' N 117° 14.3' W	Flashing GREEN (6 seconds) - 4 miles No sound Green buoy
Buoy 4 32° 37.74' N 117° 13.3' W	Quick flashing RED Bell Red buoy
Buoy 5 32° 39.1' N 117° 13.6' W	Flashing GREEN (2.5 seconds) Bell Green buoy
Buoy 6 32° 39.2' N 117° 13.5' W	Flashing RED (4 seconds) No sound Red buoy
Range	353° True (to Shelter Island West end) Front: Quick flashing GREEN (Horn) - 22' Rear: Isophase GREEN (6 seconds) - 55'

Buoy 7 32° 39.9' N 117° 13.7' W	Flashing GREEN (4 seconds) No sound Green buoy
Buoy 8 32° 39.55' N 117° 13.36' W	Flashing RED (2.5 seconds) No sound Red buoy
Zuniga Jetty Light Z 32° 40.0' W 117° 13.4' N	Flashing WHITE (2.5 seconds)- 28' - 6 miles Horn: 1 blast every 10 seconds Sign: Danger Submerged Jetty
Zuniga Jetty Light Y 32° 40.3' W 117° 13.3' N	Flashing WHITE (4 seconds) - 18' Horn: 1 blast every 10 seconds Sign: Danger Submerged Jetty
Zuniga Jetty Light X 32° 40.' W 117° 13.4' N	Flashing WHITE (4 seconds) - 18' Horn: 1 blast every 10 seconds Sign: Danger Submerged Jetty
Zuniga Jetty Light W 32° 40.7' W 117° 13.4' N	Flashing WHITE (4 seconds) - 18' Horn: 1 blast every 10 seconds Sign: Danger Submerged Jetty
Zuniga Jetty Light V 32° 40.9' W 117° 13.4' N	Flashing WHITE (4 seconds) - 16' Horn: 1 blast every 10 seconds Sign: Danger Submerged Jetty
Buoy 9 32° 40.4' N 117° 13.8' W	Flashing GREEN (2.5 seconds) No sound Green buoy
Buoy 10 32° 40.25' N 117° 13.39' W	Flashing RED (4 seconds) No sound Red buoy
Buoy 11	Flashing GREEN (4 seconds)

32° 40.9' N
117° 13.9' W

No sound
Green buoy

Buoy 12
32° 40.9' N
117° 13.7' W

Flashing RED (2.5 seconds)
No sound
Red buoy

Ballast Pt. Light B
32° 40.9' N
117° 13.7' W

Flashing WHITE (4 seconds) - 16' - 10 miles
Horn: 1 blast every 15 seconds
Platform on pile dolphin

(NO Buoy 13)

Buoy 15
32° 41.7' N
117° 13.9' W

Flashing GREEN (2.5 seconds)
No sound
Green buoy

Buoy 14
32° 41.2' N
117° 13.9' W

Quick flashing RED
No sound
Red buoy

Follow range toward west end of Shelter Island to U.S. Customs, or turn starboard to continue into the Bay

Buoy 17
32° 42.3' N
117° 13.8' W

Flashing GREEN (4 seconds)
No sound
Green buoy

Buoy 16
32° 42.1' N
117° 13.7' W

Flashing RED (2.5 seconds)
No sound
Red buoy

Buoy 16 A
32° 42.4' N
117° 13.6' W

Quick flashing RED
No sound
Red buoy

Buoy 18
32° 42.47' N
117° 13.0' W

Flashing RED (4 seconds)
No sound
Red buoy

Buoy 19
32° 42.5' N
117° 13.9' W

Quick flashing GREEN
No sound
Green buoy

At buoy 19, turn toward port and head toward Harbor Island

America's Cup Harbor
32° 43.10' N
117° 13.0' W

Flashing GREEN (4 seconds)
No sound
G "1"

Tom Hamm's Lighthouse
32° 43.27' N
117° 12.5' W

Flashing WHITE (4 seconds) - 56' - 8 miles
No sound
Light on top of restaurant

Watch for Sign (Lighted WHITE)

Turn starboard into Harbor Island west basin just past the fuel dock and before bridge